

**Kawasaki Robot
MC006V**

**Installation and
Connection Manual**

Robot

Kawasaki Heavy Industries, Ltd.

Preface

This manual describes installation and connection procedures for Kawasaki Robot MC006V.

Be sure to fully understand the content of this manual and pay attention to the safety items in this manual and the separate "Safety Manual" when performing an operation. Note that this manual only provides descriptions of the installation and connection procedures for the arm. Also see the "Installation and Connection Manual" for the controller.

Do not perform any kind of work until you fully understand all of the contents of this manual. Also, Kawasaki is not responsible for damages or problems that occur as a result of performing work after referring to specific pages only.

The explanations in the manual are applicable to the following robot.

MC006V


-
1. This manual does not constitute a guarantee of the systems in which the robot is utilized. Accordingly, Kawasaki is not responsible for any accidents, damages, and/or problems relating to industrial property rights as a result of using the system.
 2. It is recommended that all personnel assigned for activation of operation, teaching, maintenance or inspection of the robot attend the necessary education/training course(s) prepared by Kawasaki, before assuming their responsibilities.
 3. Kawasaki reserves the right to change, revise, or update this manual without prior notice.
 4. This manual may not, in whole or in part, be reprinted or copied without the prior written consent of Kawasaki.
 5. Store this manual with care and keep it available for use at any time. If the robot is reinstalled or moved to a different site or sold off to a different user, attach this manual to the robot without fail. In the event the manual is lost or damaged severely, contact Kawasaki.
-

Copyright © 2023 Kawasaki Heavy Industries Ltd. All rights reserved.


Symbols

The items that require special attention in this manual are designated with the following symbols.


Ensure proper and safe operation of the robot and prevent physical injury or property damages by complying with the safety matters given in the boxes with these symbols.

 **DANGER**

Failure to comply with indicated matters can result in imminent injury or death.

 **WARNING**


Failure to comply with indicated matters may possibly lead to injury or death.

 **CAUTION**

Failure to comply with indicated matters may lead to physical injury and/or mechanical damage.

[NOTE]

Denotes precautions regarding robot specification, handling, teaching, operation, and maintenance.

 **WARNING**

- 1. The accuracy and effectiveness of the diagrams, procedures, and detail explanations given in this manual cannot be confirmed with absolute certainty. Should any unexplained questions or problems arise, contact Kawasaki.**
- 2. Safety related contents described in this manual apply to each individual work and not to all robot work. In order to perform every work in safety, read and fully understand the "Safety Manual," all pertinent laws, regulations and related materials as well as all the safety explanation described in each chapter, and prepare safety measures suitable for actual work.**

Table of Contents

Preface	i
Symbols	ii
1 Precautions	1
1.1 Precautions during Transportation, Installation and Storage	1
1.2 Installation Environment of Robot Arm	2
2 Arm Installation and Connection Work Flow	3
3 Motion Range and Specifications	4
3.1 Determination of Safety Fence Installation Location from Motion Range	4
3.2 Motion Range and Specifications	5
4 Transportation Methods	6
4.1 Wire Suspension	6
5 Base Installation Dimensions	7
6 Installation Method	8
7 Installation of Tools	9
7.1 Wrist Tip (Flange Surface) Dimensions	9
7.2 Mounting Bolt Specifications	9
7.3 Load Capacity	10
8 Air System Connection	12
8.1 Air Piping	12
8.2 Air Supply to the Robot Arm	14
9 Connection of External Encoder Battery	15
9.1 Installation Procedures	15

1 Precautions

1.1 Precautions during Transportation, Installation and Storage

When transporting the Kawasaki Robot to its installation site, strictly observe the following cautions.



WARNING

1. When transporting the robot by crane or forklift, never allow a person to support it.
2. During transport never allow a person to ride on the robot, and never allow a person to get under it when it is suspended.
3. Before commencing installation work, be sure to turn OFF the controller power and external power, and after clearly displaying that "inspection and maintenance is in progress," lock out and tag out the external power switch so that an operator or third party does not accidentally turn ON the power, causing an unexpected situation such as electric shock.
4. When operating the robot, be sure to confirm safety points and absence of problems regarding robot installation before turning the motor power ON, and moving the robot arm to the designated position. Take care not to approach the arm and become accidentally caught when doing so. After setting the arm to the desired position, turn OFF the controller power and external power again as mentioned above, clearly indicate that "inspection and maintenance is in progress," lock out and tag out the external power switch before starting work.




CAUTION

1. The robot is made of precision parts. Be careful not to subject it to impact or shock during transport.
2. When transporting the robot by crane or forklift, clear away obstructions, etc. in advance so that the robot can be transported safely to the installation location.
3. Please pay attention to the following points when transporting or storing the robot.
 - (1) Maintain an ambient temperature within the -10°C to 60°C range.
 - (2) Maintain a relative humidity within the 35% to 85% RH range (without any condensation).
 - (3) Avoid large vibrations or shocks.
 - (4) Do not touch the robot with bare hands or hands contaminated with chlorine-based substances. The surface plating may peel off.

1.2 Installation Environment of Robot Arm


Install the robot in a location that satisfies the following conditions.

1. The robot arm installation surface must be capable of maintaining a horizontal surface within $\pm 5^\circ$.
2. The floor or frame must have adequate hardness. (Natural frequency: 30 Hz or more)
3. The location must be able to maintain flatness so that excess force is not exerted on the installed part. (If flatness cannot be ensured, adjust with a liner.)
4. The ambient operating temperature must be between 10 and 35°C.
(Starting in low temperatures increases the viscosity of grease and oil, which can lead to deviation errors and excess loads. In such cases, move the robot at low speeds before operating.)
5. Relative humidity must be 35% to 85% RH, without any condensation.
6. The location must have little dirt, dust, oil, smoke or water, etc.
(MC006V satisfies the requirements for dust and water protection grading IP65 (wrist part: IP67).)
7. The location must have no flammable or corrosive fluids or gases.*1
*1 MC006V is compatible with chemicals under specific conditions.
(For details of conditions, see “Standard Specifications.”)
8. The location must not be subject to large vibrations. (0.5 G or less)
9. The location must be well protected against electrical noise.
10. The location must safeguard a space that is larger than the robot arm's range of motion.
 - (1) Install a safety fence around the robot, and make sure that it does not interfere with surrounding equipment, even when the arm has tools attached and is extended to its maximum motion range.
 - (2) Minimize the number of entrance gates in the safety fence (only one is best) and equip the entrance gate with a safety plug. Enter and exit the fence from here.
 - (3) For details concerning safety fences, observe the ISO 10218 requirements.




2 Arm Installation and Connection Work Flow

This workflow describes only the robot arm section. For the controller, refer to “Installation and Connection Manual” for controller.




3 Motion Range and Specifications

3.1 Determination of Safety Fence Installation Location from Motion Range



The motion range of the robot described below is represented by the motion range of point P in the figure. Therefore, as shown in the figure below, install the safety fence outside the circle whose radius is $L_0+L_1+L_2$, where L_0 is the length from the center line of the arm (point A shown in the figure), L_1 is the sum of the length to the wrist flange and the maximum tool length, and L_2 is the safety margin. For the length of L_0 , see "3.2 Motion Range and Specifications."




4 Transportation Methods

4.1 Wire Suspension

Attach eyebolts to the base plate and hang a wire on it to hoist up the robot as shown in the figure below.

⚠ CAUTION

When suspending the robot, care is required as it may tip forward or backward depending on the robot posture or installation condition of the options. If the robot is suspended at an angle, the robot may swing or be damaged as a result of shock; wires may catch on the harness or piping; or external parts may cause interference resulting in damage.

Suspended posture		
Suspended posture	JT1	0°
	JT2	0°
	JT3	-150°
	JT4	0°
	JT5	-30°
	JT6	0°


5 Base Installation Dimensions

When installing the robot, use the bolt holes in the base, and fix with high tensile bolts.

Model	MC006V
Installation dimensions	
Cross-section figure of installation	
Bolt holes	—
High-tensile bolt	<p>4-M10 Material: SCM435 Hardness category: at least 10.9</p>
Tightening torque	57 N·m
Installation surface angle	Within $\pm 5^\circ$

6 Installation Method

As shown in the figure below, secure the robot to the frame using a steel plate with $\varnothing 180$ holes and thickness of at least 17 mm. Secure the frame firmly enough in order to withstand counterforce from the robot.




M (tipping moment)	725 N·m
T (rotational torque)	452 N·m
Robot base installation bolt	4-M10
Tightening torque	57 N·m
Thickness of steel plate	17 mm or more

7 Installation of Tools

⚠ WARNING


When mounting tools such as a hand, be sure to turn OFF the controller power and external power, and after clearly displaying that "inspection and maintenance is in progress," lock out and tag out the external power so that an operator or third party does not accidentally turn ON the power, causing an unexpected situation such as electric shock.

7.1 Wrist Tip (Flange Surface) Dimensions



The tip of the robot arm features a flange for mounting tools such as a hand. As shown in the left figure, tighten the mounting bolts using the tapped holes machined around the ϕD circumference of the flange. Also, use the pin holes and spigot holes to position the hand, etc.

7.2 Mounting Bolt Specifications



Select bolts with lengths that will reach the designated tightening depth, according to the tapped depths on the tool mounting flange. Additionally, use high-tensile bolts and tighten with specified torque.

⚠ CAUTION

If the bolting depth is above the specified value, then the mounting bolts will bottom out and the tool may not be secured.

Tapped holes	4-M5
ϕD	$\phi 63$
Pin hole	$\phi 5H7$ Depth 8
Spigot hole	$\phi 86h7$
Tapped depth	10.0 mm
Bolting depth	5 to 9 mm
High-tensile bolt	SCM435, 10.9 or more
Tightening torque	6.9 N·m

7.3 Load Capacity

The load mass capacity of the robot, including mass of hand, gun, etc., is fixed. Additionally, strictly observe the restrictions for load torque and load moment of inertia around each wrist axis (JT4, JT5, JT6) as shown below.

⚠ CAUTION

If a load above the specified range is applied, this can result in deteriorated operational functionality or service life. The load mass includes all items such as hand mass, tool changer mass, shock absorber mass, etc. If an amount other than the specified range will be applied, consult with Kawasaki.

The load torque and the moment of inertia can be calculated using the following formulas.

Calculation formula

Load mass : $M \leq M_{max}$. (kg)
(Hand included)

Load torque : $T=9.8 \cdot M \cdot L$ (N·m)

Load moment of inertia : $I=M \cdot L^2+I_G$ (kg·m²)

M_{max} : Maximum load mass: See 3.2.

L : Distance from center of axis rotation to load center of gravity.
(Unit: m) (See figure)

L_6 : Distance from center of axis rotation of JT6 to load center of gravity.

$L_{4,5}$: Distance from center of axis rotation of JT4(5) to load center of gravity.

I_G : Moment of inertia around center of gravity.
(Unit: kg·m²)


When calculating with the load divided between multiple locations (for example, hand and workpiece, etc.), use the total combined values as the load torque and moment of inertia.

Strictly adhere to the following restrictions regarding load of the wrist part.

1. Keep the load mass at or below 6 kg, including the hand mass.
2. There are restrictions for the load torque and load moment of inertia around each wrist axis (JT4, JT5, JT6).*1

Keep the load torque and load moment of inertia around each axis within the allowable ranges shown in the figure below.

*1 Load moment of inertia exceeding the restriction may be acceptable, but in that case, ensure to specify the load. (However, movements may be slowed due to the optimization of acceleration and deceleration.) See the “AS Language Reference Manual” for load settings. Operating the robot with wrong settings may result in degradation of movement performance and shortening of machine service life.




8 Air System Connection

8.1 Air Piping


Standard set: With valves

Valves for tool operation are housed. Without using an interlocking board, turning ON/OFF can be performed with a teach pendant.




Option set: Without valves

Air piping without valves is housed.



8.2 Air Supply to the Robot Arm



Air connection ports are located on the base part of the robot arm as shown in the figure above.

CAUTION

Supply input pressure of 0.15 to 0.6 MPa to the air supply port (VALVE).

<Reference>

When connecting air adjustment device:
For the air source for hand operation, externally connect [filter + regulator].

Note Valves housed inside the arm are of the oil-free type, so do not use any lubricator (oiler).

9 Connection of External Encoder Battery


! **WARNING**

When operating the connector of the external encoder battery, be sure to turn OFF the controller power and external power, and after clearly displaying that "inspection and maintenance is in progress," lock out and tag out the external power switch so that an operator does not accidentally turn ON the power.


Due to the structure of the encoder, MC006V may not be able to retain the encoder's rotation number data within one minute after the external encoder battery is removed. Therefore, when replacing the battery, a separate battery holder must be prepared exclusively for battery replacement work as a jig. This is to avoid a situation where the encoder battery is not connected to the arm.

9.1 Installation Procedures

1. Remove the robot with the arm attached battery from the transport pedestal.
(Being connected to the A connector.)




2. Connect the installation-dedicated battery holder from the pedestal's underside of the transport destination. (connect to the B connector.)




3. Remove the battery holder attached to the arm from the A connector.


Note Do not remove the installation battery.




4. Install the robot.



5. Mount the battery holder attached to the arm removed in step 3 on the pedestal's underside of the installing destination. (connect to the A connector.)



6. Remove the installation-dedicated battery holder from the B connector.



Kawasaki Robot MC006V
Installation and Connection Manual

2023-02 : 1st Edition

2026-01 : 3rd Edition

Publication : Kawasaki Heavy Industries, Ltd.

90202-1280DEC

Copyright © 2023 Kawasaki Heavy Industries, Ltd. All rights reserved.