


Installation Dimensions



VIEW A

RS020N
WORKING RANGE