



# Kawasaki Robot Z Series

# INSTALLATION AND CONNECTION

= Robot Arm =

ZX\*\*\*\*-B

ZT\*\*\*\*-C

ZD130S-D

ZD250S-B



Kawasaki Heavy Industries, Ltd.

#### **PREFACE**

This manual explains installing and connecting procedures for Kawasaki Robot Z series.

Read and understand the contents of this and safety manuals thoroughly and strictly observe all rules for safety before proceeding with any operation.

Never proceed with any operation until you understand the contents of this manual completely.

Kawasaki cannot take any responsibility for any accidents and/or damages caused by operations that are based on only the limited part of this manual.

This Manual describes the following Robot Arms

ZX130S, ZX130U, ZX130L, ZX165U, ZX165L,

ZX200S, ZX200U, ZX200W, ZX300G, ZX300S,

ZT130S, ZT130U, ZT130L, ZT165U,

ZT200S, ZT200U, ZT200W

ZD130S, ZD250S

- 1. This manual does not constitute a guarantee of the systems in which the robot is utilized. Accordingly, Kawasaki is not responsible for any accidents, damages, and/or problems relating to industrial property rights as a result of using the system.
- 2. It is recommended that all personnel assigned for activation of operation, teaching, maintenance or inspection of the robot attend the necessary education/training course(s) prepared by Kawasaki, before assuming their responsibilities.
- 3. Kawasaki reserves the right to change, revise, or update this manual without prior notice.
- 4. This manual may not, in whole or in part, be reprinted or copied without the prior written consent of Kawasaki.
- 5. Store this manual with care and keep it available for use at any time. If the robot is reinstalled or moved to a different site or sold off to a different user, attach this manual to the robot without fail. In the event the manual is lost or damaged severely, contact Kawasaki.

Copyright © 2009 Kawasaki Heavy Industries Ltd. All rights reserved.

#### **SYMBOLS**

The items that require special attention in this manual are designated with the following symbols.

Ensure proper and safe operation of the robot and prevent physical injury or property damages by complying with the safety matters given in the boxes with these symbols.

#### DANGER

Failure to comply with indicated matters can result in imminent injury or death.

# **WARNING**

Failure to comply with indicated matters may possibly lead to injury or death

#### **CAUTION**

Failure to comply with indicated matters may lead to physical injury and/or mechanical damage.

#### \_ [NOTE] \_\_\_

Denotes precautions regarding robot specification, handling, teaching, operation, and maintenance.

# **WARNING**

- 1. The accuracy and effectiveness of the diagrams, procedures, and detail explanations given in this manual cannot be confirmed with absolute certainty. Accordingly, it is necessary to give one's fullest attention when using this manual to perform any work.
- 2. Safety related contents described in this manual apply to each individual work and not to all robot work. In order to perform every work in safety, read and fully understand the safety manual, all pertinent laws, regulations and related materials as well as all the safety explanations described in each chapter, and prepare safety measures suitable for actual work.

# CONTENTS

1.0	Cautions	4
1.1	Precautions during Transportation and Storage	4
1.2	Installation Environments of Robot Arm	5
1.3	Warning Label	6
2.0	Motion Range & Specifications of Robot	10
3.0	Work Flow at Arm Installation and Connection	30
4.0	Robot Transportation Method	31
4.1	Wire Sling	31
4.2	Forklift	33
5.0	Installing Dimensions of Base Section	34
6.0	Movement Reaction Acting on Installation Surface during Operation	35
7.0	Installation Method	36
7.1	When Installing the Base Directly on the Floor:	36
7.2	When Installing the Base Plate with Positioning Holes on the Floor:	36
7.3	When Installing with Installation Block:	36
8.0	Mounting of Tools	37
8.1	Dimensions of Wrist End (Flange)	37
8.2	Specification of Mounting Bolts	37
8.3	Load Capacity (for ZX/ZT Series)	39
9.0	Connection of Air System	40
9.1	Air Piping Diagram	40
9.2	Air Supply to the Robot Arm	41
9.3	Connection to the Tool from the Air Outlet Port	42

#### 1.0 CAUTIONS

#### 1.1 PRECAUTIONS DURING TRANSPORTATION AND STORAGE

When transporting the Kawasaki robot to its installation position, strictly observe the following precautions:

#### WARNING

- 1. When transporting robot using a crane or a forklift, never support the robot manually.
- 2. During transportation, never climb on, or stay under the hoisted up robot.


# **CAUTION**

- 1. Since the robot body is composed of precision parts, be careful not to apply excessive shocks or vibrations to the robot during transportation.
- 2. Prior to installing the robot, remove all obstacles so the installation is carried out smoothly and safely. Clear a passage to the installation area for transportation of the robot using a crane or forklift.
- 3. During transportation and storage,
  - (1) Keep the ambient temperature within the range of -10°C~60°C,
  - (2) Keep the relative humidity within the range of 35%~85%RH without dew condensation,
  - (3) Keep free from excessively strong vibration.

#### 1.2 INSTALLATION ENVIRONMENTS OF ROBOT ARM

The robot arm must be installed in a place that satisfies all the following environmental conditions:

- 1. When robot is installed on the floor, the levelness must be within  $\pm 5^{\circ}$ .
- 2. Be sure that the floor/stand has sufficient rigidity.
- 3. Secure a flat place to prevent the base section from receiving undue force. (If an accurate flatness is unobtainable, insert liners and adjust the flatness).
- 4. Keep the ambient temperature during operation within the range of  $0^{\circ}\text{C} \sim 45^{\circ}\text{C}$ . (Deviation or overload error may occur due to high viscosity of grease/oil when starting operation at low temperatures. In this case, warm-up robot at low speed before regular operation.)
- 5. Keep the relative humidity during operation within the range of  $35\% \sim 85\%$  RH without dew condensation.
- 6. The robot installing place should be free from dust, dirt, smoke, water, and other foreign matters. (In dusty or moist condition, use an Arm with dust-proof or waterproof spec.)
- 7. The robot installing place should be free from flammable or corrosive liquid or gas. (Use an explosion-proof arm in a flammable environment.)
- 8. The robot installing place should be free from excessively strong vibration. (0.5G or less)
- 9. The robot installing place should be free from electric noise interference.
- 10. The robot installing place should be sufficiently larger than the motion range of robot arm. Safety fence must enclose area larger than the maximum motion range of fully equipped robot arm (with tools) so it does not interfere with the surrounding objects.
  - (1) An entrance gate with a safety plug should be provided to the safety fence.
  - (2) About details of the safety fence, observe the requirements which are established in each region. (e.g. EN953, EN294, EN811, EN1088, ISO13852, ISO13854, and ISO/NP 14120)




# 1.3 WARNING LABEL

#### $oldsymbol{\Lambda}$


# WARNING

Pay attention to the warning labels listed in the drawings during operation.


# **ZX SERIES**



# **ZT SERIES**




# **ZD SERIES**




#### 2.0 MOTION RANGE & SPECIFICATIONS OF ROBOT


#### **DETERMINATION OF SAFETY FENCE LOCATION BASED ON MOTION RANGE:**




The motion range of robot arm is represented by Point P in the figure above. Accordingly, the dimensions of safety should be calculated as follows: Determine sum of  $L_0$ ,  $L_1$  and  $L_2$  as minimum dimension. That is: dimension from the center of arm (Point A shown in the figure above) to the center of wrist (= $L_0$ ) + dimension from the center of wrist to the edge of tool (= $L_1$ ) + dimension of allowance (= $L_2$ ). For the dimensions of  $L_0$ , refer to the drawings of "Motion Range & Specifications of Robot" given in the following pages.



# **ZX130S**







Туре	Articulated Robot		
Degree of Freedom	6		
Motion Range	JT	Motion Range	Max. Speed
and	1	±180°	130°/s
Maximum	2	+75° ~ -60°	130°/s
Speed	3	+250° ~ -120°	130°/s
	4	±360°	180°/s
	5	±130°	180°/s
	6	±360°	280°/s
Max. Payload	130 kg		
Wrist Load	JT	Torque	Moment of Inertia
Capacity	4	735 N·m	51.9 kg·m <sup>2</sup>
	5	735 N·m	51.9 kg·m <sup>2</sup>
	6	421.4 N·m	27.4 kg·m <sup>2</sup>
Repeatability	±0.3 mm		
Mass	Approx. 1350 kg		
Acoustic noise	< 70 db (A)*		

#### \*measured condition

- installed on the plate rigidly fixed on the floor
- 4650 mm away from JT1 center

# **ZX130U**






Туре	Articulated Robot		
Degree of Freedom	6		
Motion Range	JT	Motion Range	Max. Speed
and	1	±180°	110°/s
Maximum	2	+75° ~ -60°	110°/s
Speed	3	+250° ~ -120°	110°/s
	4	±360°	140°/s
	5	±130°	135°/s
	6	±360°	230°/s
Max. Payload	130 kg		
Wrist Load	JT	Torque	Moment of Inertia
Capacity	4	735 N·m	$51.9 \mathrm{kg} \cdot \mathrm{m}^2$
	5	735 N·m	$51.9 \mathrm{kg} \cdot \mathrm{m}^2$
	6	421.4 N·m	$27.4 \text{ kg} \cdot \text{m}^2$
Repeatability	±0.3 mm		
Mass	Approx. 1350 kg		
Acoustic noise	< 70 db (A)*		

#### \*measured condition

- installed on the plate rigidly fixed on the floor
- 4650 mm away from JT1 center

# **ZX130L**





Туре	Articulated Robot		
Degree of Freedom	6		
Motion Range	JT	Motion Range	Max. Speed
and	1	±180°	110°/s
Maximum	2	+75° ~ -60°	110°/s
Speed	3	+250° ~ -120°	110°/s
	4	±360°	140°/s
	5	±130°	135°/s
	6	±360°	230°/s
Max. Payload	130kg		
Wrist Load	JT	Torque	Moment of Inertia
Capacity	4	735 N·m	51.9 kg·m <sup>2</sup>
	5	735 N·m	$51.9 \mathrm{kg} \cdot \mathrm{m}^2$
	6	421.4 N·m	27.4 kg·m <sup>2</sup>
Repeatability	±0.3 mm		
Mass	Approx. 1400 kg		
Acoustic noise	< 70 db (A)*		

#### \*measured condition

- installed on the plate rigidly fixed on the floor
- 4900 mm away from JT1 center

#### ZX165U






Туре	Articulated Robot		
Degree of Freedom	6		
Motion Range	JT	Motion Range	Max. Speed
and	1	±180°	110°/s
Maximum	2	+75° ~ -60°	110°/s
Speed	3	+250° ~ -120°	110°/s
	4	±360°	135°/s
	5	±130°	135°/s
	6	±360°	210°/s
Max. Payload	165 kg		
Wrist Load	JT	Torque	Moment of Inertia
Capacity	4	911.4 N·m	$78.4 \mathrm{kg} \cdot \mathrm{m}^2$
	5	911.4 N·m	$78.4 \mathrm{kg} \cdot \mathrm{m}^2$
	6	450.8 N⋅m	$40.2 \mathrm{kg} \cdot \mathrm{m}^2$
Repeatability	±0.3 mm		
Mass	Approx. 1350 kg		
Acoustic noise	<70 db (A)*		

#### \*measured condition

- installed on the plate rigidly fixed on the floor
- 4650 mm away from JT1 center

# ZX165L





Туре	Articulated Robot		
Degree of Freedom	6		
Motion Range	JT	Motion Range	Max. Speed
and	1	±180°	100°/s
Maximum	2	-60°∼ +75°	105°/s
Speed	3	-120°~ +250°	95°/s
	4	±360°	135°/s
	5	±130°	135°/s
	6	±360°	210°/s
Max. Payload	165 kg		
Wrist Load	JT	Torque	Moment of Inertia
Capacity	4	911.4 N·m	78.4 kg·m2
	5	911.4 N·m	78.4 kg·m2
	6	450.8 N·m	40.2 kg·m2
Repeatability	±0.3 mm		
Mass	Approx. 1355 kg		
Acoustic noise	<70 db (A)*		

#### \*measured condition

- installed on the plate rigidly fixed on the floor
- 4810 mm away from JT1 center

# **ZX200S**







Туре	Articulated Robot		
Degree of Freedom	6		
Motion Range	JT	Motion Range	Max. Speed
and	1	±180°	100°/s
Maximum	2	+75° ~ -60°	100°/s
Speed	3	+250° ~ -120°	95°/s
	4	±360°	120°/s
	5	±120°	115°/s
	6	±360°	180°/s
Max. Payload	200 kg		
Wrist Load	JT	Torque	Moment of Inertia
Capacity	4	1274 N·m	117.6 kg·m <sup>2</sup>
	5	1274 N·m	$117.6 \mathrm{kg} \cdot \mathrm{m}^2$
	6	686 N·m	$63.7 \text{ kg} \cdot \text{m}^2$
Repeatability	±0.3 mm		
Mass	Approx. 1400 kg		
Acoustic noise	< 70 db (A)*		

#### \*measured condition

- installed on the plate rigidly fixed on the floor
- 4650 mm away from JT1 center

#### **ZX200U**







Туре	Articulated Robot		
Degree of Freedom	6		
Motion Range	JT	Motion Range	Max. Speed
and	1	±180°	95°/s
Maximum	2	+75° ~ -60°	95°/s
Speed	3	+250° ~ -120°	95°/s
	4	±360°	120°/s
	5	±130°	115°/s
	6	±360°	180°/s
Max. Payload	200 kg		
Wrist Load	JT	Torque	Moment of Inertia
Capacity	4	980 N·m	93.1 kg·m <sup>2</sup>
	5	980 N·m	93.1 kg·m <sup>2</sup>
	6	490 N·m	46.1 kg·m <sup>2</sup>
Repeatability	±0.3 mm		
Mass	Approx. 1350 kg		
Acoustic noise	< 70 db (A)*		

#### \*measured condition

- installed on the plate rigidly fixed on the floor
- 4650 mm away from JT1 center

#### **ZX200W**







Туре	Articulated Robot		
Degree of Freedom	6		
Motion Range	JT	Motion Range	Max. Speed
and	1	±180°	95°/s
Maximum	2	+75° ~ -60°	95°/s
Speed	3	+250° ~ -120°	95°/s
	4	±360°	93°/s
	5	±120°	93°/s
	6	±360°	163°/s
Max. Payload	200 kg		
Wrist Load	JT	Torque	Moment of Inertia
Capacity	4	1274 N·m	$117.6 \mathrm{kg} \cdot \mathrm{m}^2$
	5	1274 N·m	$117.6 \mathrm{kg} \cdot \mathrm{m}^2$
	6	686 N·m	63.7 kg·m <sup>2</sup>
Repeatability	±0.3 mm		
Mass	Approx. 1400 kg		
Acoustic noise	< 70 db (A)*		

\*measured condition

- installed on the plate rigidly fixed on the floor
- 4650 mm away from JT1 center

# **ZX300G**







Туре	Articulated Robot		
Degree of Freedom	6		
Motion Range	JT	Motion Range	Max. Speed
and	1	±180°	100°/s
Maximum	2	+75° ~ -60°	85°/s
Speed	3	+250° ~ -120°	85°/s
	4	±360°	90°/s
	5	±120°	90°/s
	6	±360°	112°/s
Max. Payload	300 kg		
Wrist Load	JT	Torque	Moment of Inertia
Capacity	4	1715 N⋅m	166.6k g⋅m²
	5	1715 N∙m	166.6 kg·m <sup>2</sup>
	6	862.4 N·m	$192.7 \text{ kg} \cdot \text{m}^2$
Repeatability	±0.3 mm		
Mass	Approx. 1400 kg		
Acoustic noise	< 70 db (A)*		

\*measured condition

- installed on the plate rigidly fixed on the floor
- 4500 mm away from JT1 center

# **ZX300S**






Type	Articulated Robot		
Degree of Freedom	6		
Motion Range	JT	Motion Range	Max. Speed
and	1	±180°	100°/s
Maximum	2	+75° ~ -60°	85°/s
Speed	3	+250° ~ -120°	85°/s
	4	±360°	90°/s
	5	±120°	90°/s
	6	±360°	150°/s
Max. Payload	300 kg		
Wrist Load	JT	Torque	Moment of Inertia
Capacity	4	1715 N·m	166.6k g⋅m²
	5	1715 N⋅m	166.6 kg·m <sup>2</sup>
	6	862.4 N·m	$107.8 \mathrm{kg} \cdot \mathrm{m}^2$
Repeatability	±0.3 mm		
Mass	Approx. 1400 kg		
Acoustic noise	< 70 db (A)*		

\*measured condition

- installed on the plate rigidly fixed on the floor
- 4500 mm away from JT1 center

# ZT130S




Туре	Articulated Robot		
Degree of Freedom	6		
Motion Range	JT	Motion Range	Max. Speed
and	1	±180°	130°/s
Maximum	2	+60° ~ -75°	130°/s
Speed	3	+165° ~ -95°	130°/s
	4	±360°	180°/s
	5	±130°	180°/s
	6	±360°	280°/s
Max. Payload	130 kg		
Wrist Load	JT	Torque	Moment of Inertia
Capacity	4	735 N·m	51.9 kg·m <sup>2</sup>
	5	735 N·m	51.9 kg·m <sup>2</sup>
	6	421.4 N·m	27.4 kg·m²
Repeatability	±0.3 mm		
Mass	Approx. 1550 kg		
Acoustic noise	< 70 db (A)*		

\*measured condition

- installed on the plate rigidly fixed on the floor
- 5230 mm away from JT1 center

# ZT130U




Туре		Articulated Robot		
Degree of Freedom		6		
Motion Range	JT	Motion Range	Max. Speed	
and	1	±180°	105°/s	
Maximum	2	+60° ~ -75°	105°/s	
Speed	3	+165° ~ -95°	105°/s	
	4	±360°	140°/s	
	5	±130°	135°/s	
	6	±360°	230°/s	
Max. Payload		130 kg		
Wrist Load	JT	Torque	Moment of Inertia	
Capacity	4	735 N⋅m	51.9 kg·m <sup>2</sup>	
	5	735 N⋅m	51.9 kg·m <sup>2</sup>	
	6	421.4 N·m	27.4 kg·m <sup>2</sup>	
Repeatability	±0.3 mm			
Mass	Approx. 1550 kg			
Acoustic noise		< 70 db (A)*		

#### \*measured condition

- installed on the plate rigidly fixed on the floor
- 5230 mm away from JT1 center

# ZT130L




Туре	Articulated Robot				
Degree of Freedom	6				
Motion Range	JT	JT Motion Range Max. Speed			
and	1	±180°	105°/s		
Maximum	2	+60° ~ -75°	105°/s		
Speed	3	+165° ~ -95°	105°/s		
	4	±360°	140°/s		
	5	±130°	135°/s		
	6	±360°	230°/s		
Max. Payload		130 kg			
Wrist Load	JT	Torque	Moment of Inertia		
Capacity	4	980 N∙m	93.1 kg·m <sup>2</sup>		
	5	980 N·m	93.1 kg·m <sup>2</sup>		
	6	490 N·m	46.1 kg·m <sup>2</sup>		
Repeatability	±0.3 mm				
Mass	Approx. 1565 kg				
Acoustic noise		<70 db (A)*			

#### \*measured condition

- installed on the plate rigidly fixed on the floor
- 5530 mm away from JT1 center

# ZT165U




Туре		Articulated Robot			
Degree of Freedom	6				
Motion Range	JT	JT Motion Range Max. Speed			
and	1	±180°	105°/s		
Maximum	2	+60° ~ -75°	105°/s		
Speed	3	+165° ~ -95°	105°/s		
	4	±360°	135°/s		
	5	±130°	135°/s		
	6	±360°	210°/s		
Max. Payload		165 kg			
Wrist Load	JT	Torque	Moment of Inertia		
Capacity	4	911.4 N·m	78.4 kg·m <sup>2</sup>		
	5	911.4 N·m	$78.4 \mathrm{kg} \cdot \mathrm{m}^2$		
	6	450.8 N·m	$40.2 \text{ kg} \cdot \text{m}^2$		
Repeatability	$\pm 0.3~\mathrm{mm}$				
Mass	Approx. 1550 kg				
Acoustic noise		< 70 db	(A)*		

#### \*measured condition

- installed on the plate rigidly fixed on the floor
- 5230 mm away from JT1 center

# **ZT200S**




Туре	Articulated Robot				
Degree of Freedom	6				
Motion Range	JT	JT Motion Range Max. Speed			
and	1	±180°	100°/s		
Maximum	2	+60° ~ -75°	100°/s		
Speed	3	+165° ~ -95°	90°/s		
	4	±360°	120°/s		
	5	±120°	115°/s		
	6	±360°	180°/s		
Max. Payload		200 kg			
Wrist Load	JT	Torque	Moment of Inertia		
Capacity	4	1274 N⋅m	117.6 kg·m <sup>2</sup>		
	5	1274 N∙m	117.6 kg·m <sup>2</sup>		
	6	686 N·m	63.7 kg·m <sup>2</sup>		
Repeatability	$\pm 0.3  \mathrm{mm}$				
Mass	Approx. 1600 kg				
Acoustic noise		< 70 db	(A)*		

#### \*measured condition

- installed on the plate rigidly fixed on the floor
- 5230 mm away from JT1 center

# **ZT200U**




Туре	Articulated Robot				
Degree of Freedom	6				
Motion Range	JT	JT Motion Range Max. Speed			
and	1	±180°	90°/s		
Maximum	2	+60° ~ -75°	90°/s		
Speed	3	+165° ~ -95°	90°/s		
	4	±360°	120°/s		
	5	±130°	115°/s		
	6	±360°	180°/s		
Max. Payload		200 kg			
Wrist Load	JT	Torque	Moment of Inertia		
Capacity	4	980 N·m	93.1 kg·m <sup>2</sup>		
	5	980 N·m	93.1 kg·m <sup>2</sup>		
	6	490 N·m	46.1 kg·m <sup>2</sup>		
Repeatability	±0.3 mm				
Mass	Approx. 1550 kg				
Acoustic noise		< 70 db	(A)*		

#### \*measured condition

- installed on the plate rigidly fixed on the floor
- 5230 mm away from JT1 center

# **ZT200W**




Туре	Articulated Robot			
Degree of Freedom	6			
Motion Range	JT	Motion Range	Max. Speed	
and	1	±180°	90°/s	
Maximum	2	+60° ~ -75°	90°/s	
Speed	3	+165° ~ -95°	90°/s	
	4	±360°	93°/s	
	5	±120°	93°/s	
	6	±360°	163°/s	
Max. Payload		200 kg		
Wrist Load	JT	Torque	Moment of Inertia	
Capacity	4	1274 N·m	117.6 kg·m <sup>2</sup>	
	5	1274 N∙m	117.6 kg·m <sup>2</sup>	
	6	686 N·m	63.7 kg·m <sup>2</sup>	
Repeatability	$\pm 0.3 \text{ mm}$			
Mass	Approx. 1600 kg			
Acoustic noise	< 70 db (A)*			

#### \*measured condition

- installed on the plate rigidly fixed on the floor
- 5230 mm away from JT1 center

# **ZD130S**




Туре		Articulated Robot		
Degree of Freedom		4		
Motion Range	JT	Motion Range	Max. Speed	
and	1	±180°	135°/s	
Maximum	2	+90° ~ -50°	110°/s	
Speed	3	+15° ~ -120°	130°/s	
	4	±360°	300°/s	
Max. Payload		130 k	g	
Wrist Load	JT	Torque	Moment of Inertia	
Capacity	4	-	$50 \text{ kg} \cdot \text{m}^2$	
Repeatability	$\pm 0.5~\mathrm{mm}$			
Mass	Approx. 1350 kg			
Acoustic noise	< 70 db (A)*			

#### \*measured condition

- installed on the plate rigidly fixed on the floor
- 5260 mm away from JT1 center

# **ZD250S**



Туре		Articulated Robot		
Degree of Freedom		4		
Motion Range	JT	Motion Range	Max. Speed	
and	1	±180°	95°/s	
Maximum	2	+90° ~ -50°	95°/s	
Speed	3	+15° ~ -120°	95°/s	
	4	±360°	190°/s	
Max. Payload		250 k	(gg	
Wrist Load	JT	Torque	Moment of Inertia	
Capacity	4	-	$100 \mathrm{kg} \cdot \mathrm{m}^2$	
Repeatability	$\pm 0.5~\mathrm{mm}$			
Mass	Approx. 1350 kg			
Acoustic noise		< 70 db (A)*		

\*measured condition


- installed on the plate rigidly fixed on the floor
- 5260 mm away from JT1 center

#### 3.0 WORK FLOW AT ARM INSTALLATION AND CONNECTION

This flowchart describes only the robot arm section.

Installation and Connection Manual for Controller.


For the controller, refer to separate




#### 4.0 ROBOT TRANSPORTATION METHOD

#### 4.1 WIRE SLING

According to the figure, hoist up the robot by three slings through three eyebolts.






Model		ZX	ZT
	JT1	0°	0°
	JT2	-52°	-70°
Hoisting	JT3	-35°	-13°
posture	JT4	0°	0°
	JT5	-55°	-103°
	JT6	0°	0°

# **CAUTION**

When hoisting up the robot, be careful as robot may lean forward/backward depending on robot posture and mounting condition of the tool and options. If the robot is hoisted up with the base section inclined, it may swing, or the sling may interfere with the wrist motor, harness, piping etc., or it may be damaged from interfering with surrounding objects.



Model		ZD
	JT1	0°
Shipment	JT2	-45°
posture	JT3	-20°
	JT4	0°


# **CAUTION**

When hoisting up the robot, be careful as robot may lean forward/backward depending on robot posture and mounting condition of the tool and options. If the robot is hoisted up with the base section inclined, it may swing, or the wire may interfere with the wrist motor, harness, piping etc., or it may be damaged from interfering with surrounding objects.

Protect the robot with wear plates, etc. if slings interfere with a part of the robot (balancer, etc.).


# 4.2 FORKLIFT

- 1. When carrying by forklift, use the jig for the forklift installed on the robot base.
- 2. Confirm that the forks of forklift penetrate sufficiently without fail.
- 3. When transporting robot on an inclined or rough surface, be careful to maintain balance to prevent forklift/robot from falling.
- 4. When the retract stopper and retract pin (Option) are mounted set the forks of forklift to a height of 54 mm or less.



# 5.0 INSTALLING DIMENSIONS OF BASE SECTION

When installing base section, fix it with high tension bolts utilizing the bolt holes.



# 6.0 MOVEMENT REACTION ACTING ON INSTALLATION SURFACE DURING **OPERATION**


Refer to the list below for the movement reaction that acts on the installation surface during operation. Consider these values at installation shown in the following pages.

Model	ZX Series (Excluding ZX300G/S)	ZX 300G ZX 300S	ZT Series	ZD Series
M (Inversion Moment)	34000 N∙m	41000 N∙m	35000 N⋅m	26000 N⋅m
T (Rotating Torque)	12000 N·m	12000 N·m	12000 N·m	10000 N⋅m

#### 7.0 INSTALLATION METHOD

#### 7.1 WHEN INSTALLING THE BASE DIRECTLY ON THE FLOOR:

As shown in the figure below, embed steel plate (35 mm Min. thick) in the concrete floor or fix with anchor bolts. The steel plate must be fixed firmly so as to sustain reaction forces from the robot.



# 7.2 WHEN INSTALLING THE BASE PLATE WITH POSITIONING HOLES ON THE FLOOR:

1. Install the base plate utilizing 8 holes of  $\phi$ 22.


Install the base plate on the concrete floor or the steel plate floor.

Reaction forces received from robot are the same as when installing the base directly on the floor.

There are two pin holes on the base plate for positioning, which enable the base plate to join with the base precisely. Thus, replacement of a broken robot can be done quickly and easily. (Beware that usually JT1 is not precision zeroed. This function is only provided as Option.)

#### 7.3 WHEN INSTALLING WITH INSTALLATION BLOCK:

Install the installation block confirming the following dimensions are satisfied.




#### 8.0 MOUNTING OF TOOLS

### **WARNING**

When mounting tools, shut off control power up to the external power switch for shutting off power supply to the robot controller. Display signs indicating clearly "Inspection and Maintenance in progress", and lockout/tagout the external power switch to prevent personnel from accidentally turning on the power.

#### 8.1 DIMENSIONS OF WRIST END (FLANGE)


At the end of robot arm, a flange is provided for mounting a tool. Tighten the mounting bolts into the tap holes machined on circumference of  $\phi D$  as shown below. Position tool with pin holes and spigot hole.



**NOTE**: 4 tap holes marked \* require no tightening.

#### 8.2 SPECIFICATION OF MOUNTING BOLTS

Select the length of mounting bolts according to the tap depth of tool mounting flange and thickness of tool parts so that the specified screwing engagement can be attained. Use high tension mounting bolts and tighten them to the specified torque (See the table on the next page).



# **CAUTION**

If the length of engagement (screw depth) exceeds the specified depth, the mountingbolt bottoms out and the tool cannot be fixed. (ZX/ZT Series)

Kawasaki Robot	Installation and Connection Manual

Model	ZX130S, ZX130U, ZX130L, ZX165U, ZX165L, ZX200S, ZT130S, ZT130U, ZT130L, ZT165U, ZT200U	ZX200S, ZX200W ZX300G, ZX300S ZT200S, ZT200W	
Tap holes	6-M10	6-M10	
φD	ф125	φ160	
Pin holes	2-φ10H7 Depth 12	2-φ10H7 Depth 12	
Spigot hole	φ80H7 Depth 8	φ100H7 Depth 8	
Tap depth	12 mm	12 mm	
Screwing depth	10~11 mm	10~11 mm	
High tension	SCM435,	SCM435,	
bolt	10.9 Min	10.9 Min	
Tightening torque	56.84 N·m	56.84 N·m	


Model	ZD130S, ZD250S	
Drill holes	8-φ 11 (M10)	
φD	φ150	
Pin holes	-	
Spigot hole	-	
Flange	15 mm	
thickness		
High tension	SCM435,	
bolt	10.9 Min	
Tightening	56.84 N∙m	
torque	30.04 IN III	


# [NOTE]

The above mounting sizes for ZX, ZT series are based on ISO. For the dimension below, insert the adapter plate (option) prior to mounting tools.

Model	ZX130S, ZX130U, ZX130L, ZX165U, ZX165L, ZX200S, ZT130S, ZT130U, ZT130L, ZT165U, ZT200U	
Tap holes	6-M10	
φD	ф92	
Pin holes	2-ф9H7 Depth 12	
Spigot hole	φ55H7 Depth 12	
Tap depth	16 mm	
Screwing depth	14~15 mm	
High tension bolt	SCM435, 10.9 Min	
Tightening torque	56.84 N·m	

	ZX200S, ZX200W		
Model	ZX300G, ZX300S		
	ZT200S, ZT200W		
Tap holes	10-M10		
φD	φ 113		
Pin holes	2- φ 10H7 Depth 17		
Spigot hole	φ 68H7 Depth 12		
Tap depth	17 mm		
Screwing depth	15~16 mm		
High tension bolt	SCM435, 10.9 Min		
Tightening torque	56.84 N·m		





#### 8.3 LOAD CAPACITY (FOR ZX/ZT SERIES)


- 1. The load capacity of robot is specified for each model and includes the mass of tool, etc. Also, the load capacity of wrist section is provided with limiting conditions.
- 2. In addition, strictly observe the wrist load capacities in the tables on pages 11 27. Do not exceed the max. allowable load torque and load moment of inertia specified for each wrist axes (JT4, JT5, JT6).

# CAUTION

Using the robot beyond its specified load capacity may result in degradation of movement performance and shortening of machine service life. The specified range includes the tool mass such as hand, tool changer, spot weld gun, etc. To use the robot in excess of its load capacity, first contact Kawasaki without fail.

The load torque and the moment of inertia can be calculated by expressions below:

#### Calculating formula



(kg) L<sub>6</sub>: Length from JT6 axis rotating center to load

center of gravity.

L<sub>4,5</sub>: Length from JT4(5) axis rotating center to load center of gravity.

Load Mass (including tool): M≤Mmax.(kg)

Load Torque: T=9.8·M·L(N·m)

Load Moment of Inertia:  $I=M \cdot L^2 + I_G(kg \cdot m^2)$ 

Mmax.: Rated Load Mass (For example)

ZX130: 130 kg

ZX165: 165 kg

ZX200: 200 kg

ZX300: 300 kg

L: Length from axis rotating center to load

center of gravity. (Unit: m)

I<sub>G</sub>: Moment of inertia around center of

gravity. (Unit: kg·m<sup>2</sup>)


When calculating the load by dividing it into sections (for example, tool section, workpiece section, etc.), evaluate the load torque and inertia moment from the total value of each section.

#### 9.0 CONNECTION OF AIR SYSTEM

#### 9.1 AIR PIPING DIAGRAM

Z Series includes air piping for driving tool in the robot arm.

#### **ZX Series, ZT Series, ZD Series**




The following valves can be mounted on the above-mentioned arm as Option. The valve can be set ON/OFF by the Teach Pendant without interlock (ZX/ZT).

Option	Single Solenoid			1 unit
	Single Solenoid			2 units
	Single Solenoid			3 units
	Double Solenoid			1 unit
	Double Solenoid			2 units
	Double Solenoid			3 units
	Single Solenoid	1 unit +	Double Solenoid	1 unit
	Single Solenoid	1 unit +	Double Solenoid	2 units
	Single Solenoid	2 units +	Double Solenoid	1 unit

(Note) The valve specification is: CV value = 3.2 and 2-position.


#### 9.2 AIR SUPPLY TO THE ROBOT ARM

As shown in the figure below, the air connection port is provided on the base section of robot arm.




#### CAUTION

Supply input pressure; 0.147~0.588 MPa to the air inlet port (R 3/8 Joint, 2 places).



#### 9.3 CONNECTION TO THE TOOL FROM THE AIR OUTLET PORT

The air outlet port is provided on Z series robot as shown in the figure below. For ZX/ZT series, the outlet ports are  $\phi 12$  joints for air tube on the upper arm section.



# KAWASAKI ROBOT Z Series Installation and Connection = Robot Arm =

January 2003 : 1st Edition June 2009: 9th Edition

Publication: KAWASAKI HEAVY INDUSTRIES, LTD.

90202-1068DEI