Product Comparison Shows

Kawasaki Heavy Industries' Arc Welding Robots






- 1. Arc welding robots: BA series
- 2. Comparison of specifications with competitive products
- 3. Strengths of the BA Series
- 4. About the connected power supply
- **5. Examples of Applications**







- 1. Arc welding robots: BA series
- 2. Comparison of specifications with competitive products
- 3. Strengths of the BA Series only
- 4. About the connected power supply
- 5. Examples of Applications
- 6. Introducing new features



Arc welding robots BA/RA series

BAseries


Hoses and cables can be built into the hollow wrist. No interference with peripheral equipment, reducing off-line teaching review time.











RAseries

Wide range of payloads from 5kg to 20kg, and can be used for a wide range of welding targets.



RA005L









RA006L

RA010N

RA010L

RA020N

- 1. Arc welding robots: BA series
- 2. Comparison of specifications with competitive products
- 3. Strengths of the BA Series only
- 4. About the connected power supply
- 5. Examples of Applications
- 6. Introducing new features



Comparison of specifications with competitive products



Manufacturer		Kawasaki	Α	В	С	D	E	F
Maximum Payload(Kg)		6	8	10	4	8	8	10
Maximum Reach (mm)		2,036	2,028	2,010	2,006	1,809	2,000	2,010
Maximum speed (°/S)	JT1	210	200	190	195	195	175	127
	JT2	210	200	190	200	197	175	130
	JT3	220	210	210	200	205	175	125
	JT4	430	430	410	420	425	360	315
	JT5	430	430	410	420	425	360	320
	JT6	650	630	610	600	629	500	680

Highest speed performance in its class; wrist load specification optimized for hollow torches Offsetting of the upper arm allows clean handling of the wire feeder.

Comparison of specifications with competitive products



Manufacture		Kawasaki		В			
Maximum Payload(Kg)		13	12	12	12	12	12
Maximum Reach (mm)		1,492	1,098	1,420	1,441	1,441	1,440
	JT1	265	260	230	260	210	260
Maximum	JT2	250	280	225	240	210	230
speed	JT3	265	315	230	260	265	260
(°/S)	JT4	470	430	430	430	420	470
	JT5	475	430	430	450	450	470
	JT6	730	630	630	720	720	700

Outperforms competitors in payload, maximum speed per axis, and reach, and has changed the JT4 motor arrangement from BA006N, Further improved feeder mountability and enlarged hollow diameter (from ϕ 45 to ϕ 50) to accommodate high-current and high-quality arc equipment.

Comparison of specifications with competitive products



Maximum Payload(Kg)		13	12	12	12
Maximum Reach (mm)		2,093	2,009	2,272	2,010
	JT1	215	200	210	210
	JT2	215	175	210	210
Maximum speed	JT3	270	190	265	220
(°/S)	JT4	440	430	420	435
	JT5	475	430	450	435
	JT6	730	630	720	700

Outperforms competitors in payload, maximum speed per axis, and reach, and has changed the JT4 motor arrangement from BA006N,

Further improved feeder mountability and enlarged hollow diameter (from $\phi45$ to $\phi50$) to accommodate high-current and high-quality arc equipment.

- 1. Arc welding robots: BA series
- 2. Comparison of specifications with competitive products
- 3. Strengths of the BA Series only
- 4. About the connected power supply
- 5. Examples of Applications
- 6. Introducing new features



Solutions combined with cutting process

Arc welding process





Cutting/ Cutting engineering



Kawasaki Heavy Industries' robots are not only used for arc welding, but also for the pre-processing of the arc welding process. And higher cutting/cutting accuracy also means higher arc welding accuracy.

Cutting/cutting process lution

- Kawasaki offers three distinctive lineups
- 1. Gas & Plasma Cutting System
- 2. Weld Bead Cutting Robot
- 3.R Cutter Robot System



Introducing our cutting/machining solutions, which we have a lot of experience with along with arc welding

1. Gas & Plasma Cutting System

- Thin plate plasma cutting for chemical and food tanks
- Gas cutting of thick plates for construction machinery parts

t e y e territ e e ringui e e e e e			
robot	FA010NFD20 1unit		
	running, expansion and		
peripherals	contraction、elevating equipment		
periprierais	tool changer、laying out、		
	cutting、Touch Probe		
application	cutting		
notes	KCONG		





feature


Together with defining the mirror plate by parametric input, By selecting a figure for creasing or cutting, NC data for creasing and cutting by the robot is generated and output, and the robot performs creasing and cutting without teach-in.

2. Weld Bead Cutting Robot

- This robot system performs bead cutting (weld finishing) work on the outer circumference welds of structures.
- Before cutting, workpiece position is automatically compensated by automatic touch sensing of the workpiece.
- Automatic tool change enables long-time machining and application-specific cutting.

system configuration >

robot	BX200L 1unit
	traveling gear, tool changer
peripherals	Spindle motor、
periprierais	Touch Probe、
	End mills (various types)
application	cutting
notes	KCONG





feature

Fully automated cutting from sensing to the end of machining

3. R Cutter Robot System

- This robot system performs bead cutting (weld finishing) of the outer circumference welds of structures.
- Before cutting, workpiece position is automatically compensated by automatic touch sensing of the workpiece.
- · Automatic tool change enables long-time machining and application-specific cutting.

robot	RS080N 2units		
	vision camera		
peripherals	Laser sensor		
periprierais	KCONG		
	processing table		
application	chamfering		
notes			





feature

Realization of 2R automatic machining equipment, automatic recognition of workpiece shape and start of machining


- 1. Arc welding robots: BA series
- 2. Comparison of specifications with competitive products
- 3. Strengths of the BA Series only
- 4. About the connected power supply
- 5. Examples of Applications
- 6. Introducing new features




Connectable power supply that can be connected to Kawasaki Robot

Connects to most major power supplies

The system is compatible with most of the power sources used in arc welding, This allows for flexible support at various sites.





Example of function development to ensure weld quality Continuous arc spot welding function


Summary

By setting the minimum required welding points and welding intervals, arc spot welding points are automatically generated.

Request from a system integrator in China. Quality assurance of thin plate welding using inexpensive welding equipment.

Essentially, a high-performance (pulse welding) power supply is required.







- 1. Arc welding robots: BA series
- 2. Comparison of specifications with competitive products
- 3. Strengths of the BA Series only
- 4. About the connected power supply
- 5. Examples of Applications
- 6. Introducing new features



Application Examples

Reliable Robot Welds for More Than 20 Years




Introduction of automated arc welding of motor cycle parts

Article detail URL

https://kawasakirobotics.com/case-studies/reliable-robot-welds-for-more-than-20-years/



Welding and cutting of large steel materials



Introduction of automated arc welding process in the process of making construction materials for a huge overpass.

Article detail URL

https://kawasakirobotics.com/jp/case-studies/case_khf/

- 1. Arc welding robots: BA series
- 2. Comparison of specifications with competitive products
- 3. Strengths of the BA Series only
- 4. About the connected power supply
- 5. Examples of Applications
- 6. Introducing new features



Operate multiple controllers with just one Teach pendant

New features


Cooperative welding operation of up to 4 robots is possible with one TP



23

New Teach pendant screen

Teach pendant Gen II



Programming and monitoring robots

Arc setting

Contact us



© Kawasaki Heavy Industries, Ltd. All Rights Reserved

Click here for more information. Kawasaki's staff will do their best to support you!

https://kawasaki-corporate.spiral-site.com/ind_robot_asia

Kawasaki, working as one for the good of the planet

"Global Kawasaki"

